

FINISHING GUIDE

Material Overview

All Century products with the exception of Centreflex™ Radius and Formaflex™ Contour mouldings, are shipped pre-primed and ready to paint.

Centreflex Radius and Formaflex Contour mouldings are shipped un-primed and must be primed before finishing.

Pre-Finishing Overview – All Polymer Products

- 1 You can finish [paint or faux finish] moulding before or after installation.
- 2 Option: You may want to tack or secure moulding or accessories into place using finishing nails. If you want to remove nails after construction adhesive dries, leave approximately ½" nail exposed for easy removal. TIP: Nail components into the face of moulding into wall. When adhesive dries [approx. 2-3 hours] either remove finishing nails or use nail set to countersink nails, making sure that nails penetrate wall at least ½" to ¾".
- 3 Fill nail holes with elastomeric adhesive caulk – smooth the surface with your finger or putty knife. Once caulk is dry and if needed, *lightly* sand any rough spots with extra fine sandpaper.
- 4 Paint or touch up moulding or accessory with paint as needed.

Pre-Finishing – All Fiberglass Products

- 1 You can finish [paint or faux finish] niche or dome before or after installation.
- 2 Once niche or dome is installed paint or touch up product as needed.

Painting guide

- 1 All Century products can be used in both interior and exterior applications.
- 2 When installed in an exterior application, product must be finished with exterior paint and recommended finishing coat for intended application.
- 3 Always use a high-quality latex or oil-based paint that is manufactured for intended purpose. Follow paint manufacturer's application instructions.

NEVER USE LACQUER BASED PAINTS!